



**RD350LC/  
RD350LCF '86**  
1UA-AE1

# **SUPPLEMENTARY SERVICE MANUAL**


---

## CONTENTS

<b>GENERAL INFORMATION</b> .....	1
<b>MOTORCYCLE IDENTIFICATION</b> .....	1
FRAME SERIAL NUMBER .....	1
ENGINE SERIAL NUMBER .....	1
<b>PERIODIC INSPECTIONS AND ADJUSTMENTS</b> .....	2
<b>INTRODUCTION</b> .....	2
<b>PERIODIC MAINTENANCE/LUBRICATION INTERVALS</b> .....	2
<b>COWL</b> .....	4
SIDE COVER .....	4
<b>ENGINE</b> .....	5
AUTOLUBE PUMP CABLE ADJUSTMENT .....	5
ENGINE OIL LEVEL CHECK .....	6
<b>CHASSIS</b> .....	8
FRONT FORK OIL CHANGE .....	8
REAR SHOCK ABSORBER ADJUSTMENT .....	10
<b>ELECTRICAL</b> .....	11
HEADLIGHT BULB REPLACEMENT .....	11
HEADLIGHT BEAM ADJUSTMENT .....	11
TAILLIGHT BULB(S) REPLACEMENT .....	13
IGNITION TIMING CHECK .....	15
<b>CHASSIS</b> .....	17
<b>REAR SHOCK ABSORBER</b> .....	17
HANDLING NOTES .....	18
NOTES ON DISPOSAL .....	18
REMOVAL .....	18
INSPECTION .....	20
INSTALLATION .....	20
<b>SWINGARM</b> .....	22
REMOVAL .....	23
INSPECTION .....	24
INSTALLATION .....	24
<b>ELECTRICAL</b> .....	27
<b>CIRCUIT DIAGRAM</b> .....	27
FOR AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY AND NORWAY .....	27
EXCEPT FOR AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY AND NORWAY .....	29
<b>ELECTRICAL COMPONENTS</b> .....	31
<b>IGNITION SYSTEM</b> .....	33
TROUBLESHOOTING .....	35

---

<b>APPENDICES</b>	43
<b>SPECIFICATIONS</b>	43
GENERAL SPECIFICATIONS (FOR RD350LCF)	43
GENERAL SPECIFICATIONS (FOR RD350LC)	45
MAINTENANCE SPECIFICATIONS	46
Engine (For RD350LCF)	46
Engine (For RD350LC)	47
Tightening torque	48
Chassis	49
Electrical	50
<b>CABLE ROUTING</b>	52
FOR RD350LCF	52
FOR RD350LC	56
<b>WIRING DIAGRAM</b>	



## ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑧ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Engine
- ④ Cooling system
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Appendices

Illustrated symbols ⑨ to ⑭ are used to identify the specifications appearing in the text.

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Tightening
- ⑫ Wear limit, clearance
- ⑬ Engine speed
- ⑭  $\Omega$ , V, A

Illustrated symbols ⑮ to ㉑ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑮ Apply engine oil
- ⑯ Apply gear oil
- ⑰ Apply molybdenum disulfide oil
- ⑱ Apply wheel bearing grease
- ⑲ Apply lightweight lithium-soap base grease
- ⑳ Apply molybdenum disulfide grease
- ㉑ Apply locking agent (LOCTITE®)



---

## NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent in motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

TECHNICAL PUBLICATIONS  
SERVICE DIVISION  
MOTORCYCLE OPERATIONS  
YAMAHA MOTOR CO., LTD.

## HOW TO USE THIS MANUAL

### PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation.

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings  
Pitting/Damage → Replace.

### EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.

---

## FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and new data for the RD350LC/RD350LCF. For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manual.


<p><b>RD250LC/RD350LC SERVICE MANUAL (31L-28197-80)</b> <b>RD350/350F SUPPLEMENTARY SERVICE MANUAL (57V-AE1)</b></p>
--

<p><b>RD350LC/RD350LCF</b> <b>SUPPLEMENTARY SERVICE MANUAL</b> ©1986 by Yamaha Motor Co., Ltd. 1st Edition, February 1986 All rights reserved. Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd. is expressly prohibited.</p>
---

GENERAL  
INFORMATION

MOTORCYCLE IDENTIFICATION  
FRAME SERIAL NUMBER

The frame serial number ① is stamped into the right side of the steering head pipe.




ENGINE SERIAL NUMBER

The engine serial number ① is stamped into the elevated part of the left rear section of the engine.

NOTE: \_\_\_\_\_

The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.



Starting Serial Number:	
RD350LC	
1UA .....	1WT-005101
1XA .....	1WW-002101
1XE .....	1WX-002101
RD350LCF	
1WT .....	1WT-000101
1WU .....	1WU-000101
1WW .....	1WW-000101
1WX .....	1WX-000101

NOTE: \_\_\_\_\_

Designs and specifications are subject to change without notice.

## PERIODIC INSPECTIONS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

### PERIODIC MAINTENANCE/LUBRICATION INTERVALS

Unit: km (mi)

ITEM	REMARKS	BREAK-IN 1,000 (600)	EVERY	
			6,000 (4,000) or 6 Months	12,000 (8,000) or 12 Months
Spark plug(s)	Check condition. Clean or replace if necessary.	○	○	○
Air filter	Clean. Replace if necessary.		○	○
Carburetor*	Check idle speed (/synchronization)/ starter operation. Adjust if necessary.	○	○	○
Fuel line*	Check fuel hose (and vacuum pipe) for cracks or damage. Replace if necessary.		○	○
Transmission oil*	Check oil level/oil leakage. Correct if necessary. Replace every 24,000 (16,000) or 24 months. (Warm engine before draining.)	REPLACE	○	○
Autolube pump*	Check operation. Correct if necessary. Air bleeding.	○	○	○
Brake*	Check operation/fluid leakage/See NOTE. Correct if necessary.		○	○
Clutch	Check operation. Adjust if necessary.		○	○
Rear arm pivot*	Check rear arm assembly for looseness. Correct if necessary. Moderately repack every 24,000 (16,000) or 24 months.			○
Rear suspension link pivots*	Check operation. Apply grease lightly every 24,000 (16,000) or 24 months.			○
Wheels*	Check balance/damage/runout. Repair if necessary.		○	○
Wheel bearings*	Check bearings assembly for looseness/ damage. Replace if damaged.		○	○
Steering bearing*	Check bearings assembly for looseness. Correct if necessary. Moderately repack every 24,000 (16,000) or 24 months. **	○		○
Front forks*	Check operation/oil leakage. Repair if necessary.		○	○
Rear shock absorber*	Check operation./oil leakage. Repair if necessary.		○	○

Unit: km (mi)

ITEM	REMARKS	BREAK-IN 1,000 (600)	EVERY	
			6,000 (4,000) or 6 Months	12,000 (8,000) or 12 Months
Cooling system	Check coolant leakage. Repair if necessary. Replace coolant every 24,000 (16,000) or 24 months.		○	○
Drive chain	Check chain slack/alignment. Adjust if necessary. Clean and lube.	EVERY 500 (300)		
Fittings/Fasteners*	Check all chassis fittings and fasteners. Correct if necessary.	○	○	○
Center and sidestand*	Check operation. Repair if necessary.	○	○	○
Sidestand switch*	Check operation. Clean or replace if necessary. (E)(G)(S)(D)(N)(Sw)(Ar)	○	○	○
Battery*	Check specific gravity. Check breather pipe for proper operation. Correct if necessary.		○	○

\*: It is recommended that these items be serviced by a Yamaha dealer.

\*\*: Medium weight wheel bearing grease.

\*\*\*: Lithium soap base grease.

## NOTE:

### Brake fluid replacement:

1. When disassembling the master cylinder, or caliper cylinder, replace the brake fluid.  
Normally check the brake fluid level and add the fluid as required.
2. On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
3. Replace the brake hoses every four years, or if cracked or damaged.

(E) For England  
(D) For Denmark  
(Ar) For Austria

(G) For Germany  
(N) For Norway

(S) For Switzerland  
(Sw) For Sweden




## COWL

### SIDE COVER

#### Removal


1. Remove:
  - Seat
  - Cover (Center)




**NOTE:** \_\_\_\_\_  
 Unhook the cover at front and pull out it toward the front.  
 \_\_\_\_\_



2. Remove:
  - Owner's tool kit
  - Grab bar



3. Remove:
  - Side cover ① (Left)



4. Remove:
  - Side cover ① (Right)


### Installation

Reverse the removal procedure.

Note the following points.

1. Install:

- Grab bar

	<b>Bolts (Grab Bar):</b> <b>15 Nm (1.5 m•kg, 11 ft•lb)</b>
---	---

2. Install:

- Cover (center)

**NOTE:** \_\_\_\_\_

Insert the holding rods on the cover into the rod holes on the tail cover.

\_\_\_\_\_

3. Install:

- Seat

**NOTE:** \_\_\_\_\_

Insert the lobe on the seat front into the receptacle on the frame, then push down the seat at the end.

\_\_\_\_\_




## ENGINE

### AUTOLUBE PUMP CABLE ADJUSTMENT

**NOTE:** \_\_\_\_\_

Before adjusting Autolube cable always set carburetors synchronization and throttle cable free play first.


\_\_\_\_\_



1. Remove:

- Lower cowl (For RD350LCF)
- Right center cowl (For RD350LCF)
- Autolube pump cover ①


## ENGINE OIL LEVEL CHECK



2. Fully open the throttle grip.  
Hold this position.

3. Check:

- Alignment mark ①  
Mark and pin are not in alignment → Adjust pump cable.



**Autolube pump cable adjustment steps:**

- Loosen the locknut ①.
- Turn the adjuster ② in or out until the alignment mark is aligned.
- Tighten the locknut.

4. Install:

- Autolube pump cover
- Right center cowl (For RD350LCF)
- Lower cowl (For RD350LCF)





## ENGINE OIL LEVEL CHECK

1. Check:

- Oil level  
Oil level low → Add sufficient oil.  
Refer to next chart.



Oil Level and "Oil" Warning Indicator Light Checking Method



\*  
NOTE:


If the main switch is turned off after the oil warning light goes out and then immediately again the main switch is turned on, the oil warning light may not come on. This is not because of failure.

- A

For RD350LC
- B

For RD350LCF

① "OIL" warning indicator light



Recommended Oil:

Yamaha Oil 2T or Equivalent  
Aircooled 2-stroke Engine Oil

Oil Quantity:

Total Amount:

1.6 L (1.4 Imp qt, 1.7 US qt)

NOTE:

Be sure to push the cap into the filler neck until it is properly seated.

① Oil tank cap


## CHASSIS

### FRONT FORK OIL CHANGE

#### **WARNING:**

- Fork oil leakage can cause loss of stability and safe handling. Have any problem corrected before operating the motorcycle.
- Securely support the motorcycle so there is no danger of it falling over.

1. Remove:
  - Lower cowl (For RD350LCF)
2. Place the motorcycle on a block or other suitable stand under the frame.




3. Remove:
  - Fork cap (1)  
Turn counterclockwise.
4. Loosen:
  - Pinch bolt (Handlebar) (2)
  - Pinch bolt (Steering crown) (3)
5. Keep the valve open by pressing it for several seconds so that the air can be let out of the inner tube.



6. Remove:
  - Cap (1)
  - Stopper ring (2)

#### **NOTE:**

Push down the cap using socket wrench, and remove the stopper ring by carefully prying out one end with a small screwdriver.



7. Remove:
  - Drain screw (1)  
Drain the fork oil.

#### **NOTE:**

Place the open container under the drain hole.

### WARNING:

Do not allow any oil to contact the disc brake components. If oil is discovered be sure to remove it, otherwise diminished braking capacity and damage to the rubber components of the brake assembly will occur.



8. Inspect:
- O-ring ①
  - Gasket (Drain screw)
- Wear/Damage → Replace.


9. Install:
- Drain screw

10. Fill:
- Front forks



**Each Fork:**  
 293 cm<sup>3</sup> (10.3 Imp oz, 9.1 US oz)  
 Fork Oil 10 WT or Equivalent

After filling, pump the forks slowly up and down to distribute the oil.



11. Install:
- Cap
  - Stopper ring
12. Tighten:
- Pinch bolt (Steering crown) ①
  - Pinch bolt (Handlebar) ②



**Pinch Bolt (Steering crown):**  
 23 Nm (2.3 m•kg, 17 ft•lb)  
**Pinch Bolt (Handlebar):**  
 20 Nm (2.0 m•kg, 14 ft•lb)

## REAR SHOCK ABSORBER ADJUSTMENT



### 13. Fill:

- Front fork
- Supply the air to specification.

**Standard Air Pressure:**  
**39.2 kPa (0.4 kg/cm<sup>2</sup>, 5.7 psi)**

### 14. Install:


- Fork cap
- Lower cowl (For RD350LCF)

## REAR SHOCK ABSORBER ADJUSTMENT

The spring pre-load of the rear shock absorber can be adjusted to suit rider preference, weight and the course conditions.

### 1. Remove:

- Side cover (Right)
- Refer to "SIDE COVER" section.



### 2. Adjust:

- Spring pre-load

**To Increase Pre-load:**  
**Turn Clockwise**  
**To Decrease Pre-load:**  
**Turn Counterclockwise**



	Hard			STD	Soft		
Adjusting position	7	6	5	4	3	2	1



**NOTE:** \_\_\_\_\_

When adjusting, use the special wrench which is included in the owner's tool kit.

### Recommended Combinations (Front Fork and Rear Shock Absorber)

Recommended combinations of the front fork and the rear shock absorber. Use this table as a guide to meet specific riding conditions and motorcycle load conditions.

	Front fork	Rear shock absorber	Loading condition			
	Air pressure	Spring seat	Solo rider	With accessory equipment	With passenger	With accessory equipment and passenger
1.	39.2 kPa (0.4 kg/cm <sup>2</sup> , 5.7 psi)	4	○			
2.	58.8 kPa (0.6 kg/cm <sup>2</sup> , 8.5 psi)	5		○		
3.	78.5 kPa (0.8 kg/cm <sup>2</sup> , 11.4 psi)	6			○	
4.	98.1 kPa (1.0 kg/cm <sup>2</sup> , 14.2 psi)	7				○



## ELECTRICAL


### HEADLIGHT BULB REPLACEMENT

For RD350LCF

1. Remove:
  - Meter assembly ①
  
2. Disconnect:
  - Headlight connector ①
  
3. Remove:
  - Cover ②

## HEADLIGHT BULB REPLACEMENT

INSP  
ADJ




4. Remove:

- Bulb holder ①  
Turn counterclockwise.
- Bulb ②

**WARNING:**

Do not touch headlight bulb when it is on as the bulb generates enormous heat; keep flammable objects away.



5. Install:

- Bulb (New)

**CAUTION:**

Avoid touching glass part of bulb. Also keep it free from oil otherwise, transparency of glass, bulb life and illuminous flux will be adversely affected. If oil gets on bulb, clean it with a cloth moistened thoroughly with alcohol or lacquer thinner.

6. Install:

- Bulb holder
- Cover

7. Connect:


- Headlight connector

8. Adjust:

- Headlight

9. Install:

- Meter assembly





For RD350LC

1. Remove:

- Headlight lens unit

2. Disconnect:

- Headlight lead



3. Remove:
- Bulb holder ①  
Turn counterclockwise.
  - Bulb

WARNING:



Do not touch headlight bulb when it is on as the bulb generates enormous heat; keep flammable objects away.

4. Install:
- Bulb (New)

CAUTION:

Avoid touching glass part of bulb. Also keep it free from oil otherwise, transparency of glass, bulb life and illuminous flux will be adversely affected. If oil gets on bulb, clean it with a cloth moistened thoroughly with alcohol or lacquer thinner.

5. Install:
- Bulb holder
  - Headlight lens unit



HEADLIGHT BEAM ADJUSTMENT


For RD350LCF

1. Adjust:
- Headlight beam

Horizontal Adjustment	
Right	Turn adjusting knob ① clockwise
Left	Turn adjusting knob ① counterclockwise

Vertical adjustment	
Higher	Turn the adjusting knob ② counterclockwise
Lower	Turn the adjusting knob ② clockwise

## TAILLIGHT BULB(S) REPLACEMENT




For RD350LC

1. Adjust:
  - Headlight beam

Horizontal Adjustment	
Left	Turn adjusting screw ① clockwise
Right	Turn adjusting screw ① counterclockwise


Vertical adjustment	
Lower	Turn the adjusting screw ② counterclockwise
Higher	Turn the adjusting screw ② clockwise




## TAILLIGHT BULB(S) REPLACEMENT

1. Remove:
  - Seat
  - Tool kit
  - Tool box
2. Remove:
  - Bulbs

Turn the bulb counterclockwise and remove.
3. Install:
  - Bulbs (New)
4. Connect:
  - Taillight connector
5. Install:
  - Tool box
  - Tool kit
  - Seat








## IGNITION TIMING CHECK

### 1. Removal:

- Lower cowl (For RD350LCF)  
Refer to "LOWER COWL" section.
- Change pedal ①
- Crank case cover (Left) ②




### 2. Check:

- Ignition timing

### Ignition timing check steps:

- Connect the Timing Light (90890-03109) ① to the left side cylinder spark plug lead.
- Warm up the engine and let it at the specified speed of 1,200 r/min.
- Visually check the stationary pointer ② to verify it is within the required firing range ③ indicated on the flywheel.  
Incorrect firing range → Check timing plate and/or pickup assembly (tightness damage).



Refer to CHAPTER 7. "ELECTRICAL" for further information.

### 3. Install:

- Crankcase cover (Left)
- Change pedal
- Lower cowl (For RD350LCF)

---


**MEMO**



## CHASSIS

REAR SHOCK ABSORBER  
(MONOCROSS SUSPENSION "DE CARBON" SYSTEM)

- ① Rear shock absorber
- ② Bush
- ③ Solid bush
- ④ Dust cover






## HANDLING NOTES

### WARNING:

This shock absorber contains highly pressurized nitrogen gas. Read and understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.

1. Do not tamper with or attempt to open the cylinder assembly.
2. Do not subject shock absorber to an open flame or other high heat source. This may cause the unit to explode due to excessive gas pressure.
3. Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.




### NOTES ON DISPOSAL

Before disposing the shock absorber, be sure to extract the nitrogen gas. To do so, drill a 2~3 mm (0.08~0.12 in) hole through the gas chamber at a position 10~15 mm (0.4~0.6 in) from top end of the rear shock absorber. At this time, wear eye protection to prevent eye damage from escaping gas and/or metal chips.


- ① Drill  $\phi 2 \sim 3$  mm ( $\phi 0.08 \sim 0.12$  in)

### REMOVAL


1. Place the motorcycle on its centerstand.
2. Remove:
  - Seat
  - Side covers (Right and left)
 Refer to "SIDE COVER" section.




3. Remove:
- Lower cowl (For RD350LCF)



4. Remove:
- Exhaust pipes



5. Remove:
- Bolts (Oil tank)




6. Remove:
- Battery

**CAUTION:**

---

Disconnect the negative lead first, and then disconnect the positive lead.

---



### 7. Remove:

- Rear shock absorber

## INSPECTION

### 1. Inspect:

- Shock absorber  
Oil leaks/Damage→Replace.



### 2. Inspect:

- Collar  
Wear/Damage→Replace.
- Solid bushes  
Wear/Damage→Replace.
- Bush  
Wear/Damage→Replace.

## INSTALLATION

Reverse the removal procedure.


Note the following points.

### 1. Apply:

- Grease  
To collar, solid bushes and bush.



**Lightweight Lithium-Soap Base Grease**




### 2. Install:

- Rear shock absorber




**Nut (Upper):**  
40 Nm (4.0 m•kg, 29 ft•lb)  
**Nut (Lower):**  
65 Nm (6.5 m•kg, 47 ft•lb)




3. Install:
- Mufflers



Bolt (Muffler):  
 64 Nm (6.4 m•kg, 46 ft•lb)






Nut (Exhaust Pipe):  
 18 Nm (1.8 m•kg, 13 ft•lb)



# SWINGARM

- |                |                |
|----------------|----------------|
| ① Swingarm     | ⑪ Thrust cover |
| ② Relay arm    | ⑫ Collar       |
| ③ Arm (Right)  | ⑬ Bush         |
| ④ Arm (Left)   | ⑭ Oil seal     |
| ⑤ Oil seal     | ⑮ Thrust cover |
| ⑥ Bush         | ⑯ Collar       |
| ⑦ Thrust cover | ⑰ Bush         |
| ⑧ Plain washer |                |
| ⑨ Bush         |                |
| ⑩ Bearing      |                |





**REMOVAL**

1. Place the motorcycle on its centerstand.
2. Remove:
  - Rear wheel
  - Rear shock absorberRefer to "REAR SHOCK ABSORBER-REMOVAL" section.
3. Check:
  - Swingarm (Side play)Move the swingarm from side to side.  
Over specified limit→Replace bushes or bearings.







**Side Play (At End of Swingarm):**  
**1.0 mm (0.04 in)**

4. Check:
  - Swing arm (Vertical movement)Move the swingarm up and down.  
Tightness/Binding/Rough spots→Replace bearings.

5. Remove:
  - Relay arm

6. Remove:
  - Chain cover
  - Swingarm





## 7. Remove:

- Arm (Right)
- Arm (Left)

## INSPECTION

### 1. Inspect:

- Oil seals  
Damage → Replace.
- Thrust covers  
Damage → Replace.
- Bushes  
Scratches/ Damage → Replace.
- Bearings  
Pitting/ Damage → Replace.

## INSTALLATION

Reverse the removal procedure.  
Note the following points.

### 1. Apply:

- Grease



**Lightweight Lithium-Soap Base Grease**

- ① Oil seal
- ② Bush
- ③ Oil seal

### 2. Install:

- Arm (Left)
- Arm (Right)



**Nut (Arm):**  
**40 Nm (4.0 m•kg, 29 ft•lb)**



### 3. Apply:


- Grease



**Lightweight Lithium-Soap Base Grease**

- ① Thrust cover
- ② Bush
- ③ Collar
- ④ Bush
- ⑤ Thrust cover





4. Install:
- Relay arm




**Nut (Relay Arm):**  
40 Nm (4.0 m•kg, 29 ft•lb)

5. Apply:
- Grease



**Lightweight Lithium-Soap Base Grease**



- ① Thrust cover
- ② Bush
- ③ Bearing
- ④ Bearing
- ⑤ Thrust cover

6. Install:
- Swingarm




**Nut (Pivot Axle):**  
70 Nm (7.0 m•kg, 50 ft•lb)

7. Apply:
- Grease



**Lightweight Lithium-Soap Base Grease**




- ① Collar
- ② Bush
- ③ Oil seal
- ④ Thrust cover

8. Tighten:
- Nut



**Arm and Relay Arm**  
65 Nm (6.5 m•kg, 47 ft•lb)



9. Apply:
- Grease



Lightweight Lithium-Soap Base Grease.

- ① Grease nipple

10. Install:

- Rear shock absorber
- Mufflers

Refer to "REAR SHOCK ABSORBER-INSTALLATION" section.

11. Install:

- Rear wheel



Nut (Rear Axle):


105 Nm (10.5 m•kg, 75 ft•lb)



## ELECTRICAL

## RD350LC/RD350LCF CIRCUIT DIAGRAM

(FOR AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY AND NORWAY)





- |                          |   |
|--------------------------|---|
| ① CDI magneto            | ②④ "TURN" switch                        |
| ② Rectifier/Regulator    | ②⑤ "TURN" indicator light               |
| ③ Main switch            | ②⑥ Left flasher light (Front and rear)  |
| ④ Fuse (MAIN)            | ②⑦ Right flasher light (Front and rear) |
| ⑤ Battery                | ②⑧ "OIL" indicator light                |
| ⑥ Fuse (Y.P.V.S.)        | ②⑨ Oil level switch                     |
| ⑦ YPVS control unit      | ③⑩ "NEUTRAL" indicator light            |
| ⑧ Servomotor             | ③⑪ Neutral switch                       |
| ⑨ Sidestand control unit | ③⑫ Rear brake switch                    |
| ⑩ "ENGINE STOP" switch   | ③⑬ Front brake switch                   |
| ⑪ Sidestand switch       | ③⑭ Fuse (SIGNAL)                        |
| ⑫ CDI unit               | ③⑮ Tail/Brake light                     |
| ⑬ Ignition coil          | ③⑯ Auxiliary light                      |
| ⑭ Spark plug             | ③⑰ Fuse (HEAD)                          |
| ⑮ Pickup coil            | ③⑱ "LIGHTS" switch                      |
| ⑯ Tachometer             | ③⑲ "PASS" switch                        |
| ⑰ Temperature gauge      | ④⑰ Meter light                          |
| ⑱ Thermo switch          | ④⑱ "LIGHTS" (Dimmer) switch             |
| ⑲ Horn                   | ④⑲ Headlight                            |
| ⑳ "HORN" switch          | ④⑲ "HIGH BEAM" indicator light          |
| ㉑ Cancelling unit        | ④⑲ Except for Germany                   |
| ㉒ Reed switch            | ④⑲ For Germany                          |
| ㉓ Flasher relay          |   |


### COLOR CODE

B	Black	L/R	Blue/Red
R	Red	B/Y	Black/Yellow
O	Orange	B/W	Black/White
L	Blue	B/R	Black/Red
P	Pink	R/W	Red/White
Y	Yellow	R/Y	Red/Yellow
G	Green	W/R	White/Red
W	White	W/B	White/Black
Ch	Chocolate	W/G	White/Green
Dg	Dark green	Y/L	Yellow/Blue
Gy	Gray	Y/R	Yellow/Red
Sb	Sky blue	Y/G	Yellow/Green
Br	Brown	G/R	Green/Red
L/B	Blue/Black	G/Y	Green/Yellow
L/W	Blue/White	Br/W	Brown/White
L/Y	Blue/Yellow		



## RD350LC/RD350LCF CIRCUIT DIAGRAM

(EXCEPT FOR AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY AND NORWAY)





- |                        |   |
|------------------------|---|
| ① CDI magneto          | ②② "TURN" switch                        |
| ② Rectifier/Regulator  | ②③ "TURN" indicator light               |
| ③ Main switch          | ②④ Left flasher light (Front and rear)  |
| ④ Fuse (MAIN)          | ②⑤ Right flasher light (Front and rear) |
| ⑤ Battery              | ②⑥ "OIL" indicator light                |
| ⑥ Fuse (Y.P.V.S.)      | ②⑦ Oil level switch                     |
| ⑦ YPVS control unit    | ②⑧ "NEUTRAL" indicator light            |
| ⑧ Servomotor           | ②⑨ Neutral switch                       |
| ⑨ "ENGINE STOP" switch | ③⑩ Rear brake switch                    |
| ⑩ CDI unit             | ③⑪ Front brake switch                   |
| ⑪ Ignition coil        | ③⑫ Fuse (SIGNAL)                        |
| ⑫ Spark plug           | ③⑬ Tail/Brake light                     |
| ⑬ Pickup coil          | ③⑭ Auxiliary light                      |
| ⑭ Tachometer           | ③⑮ Fuse (HEAD)                          |
| ⑮ Temperature gauge    | ③⑯ "LIGHTS" switch                      |
| ⑯ Thermo switch        | ③⑰ "PASS" switch                        |
| ⑰ Horn                 | ③⑱ Meter light                          |
| ⑱ "HORN" switch        | ③⑲ "LIGHT" (Dimmer) switch              |
| ⑲ Cancelling unit      | ④⑰ Headlight                            |
| ⑳ Reed switch          | ④⑱ "HIGH BEAM" indicator light          |
| ㉑ Flasher relay        |   |


### COLOR CODE

B	Black	L/R	Blue/Red
R	Red	B/Y	Black/Yellow
O	Orange	B/W	Black/White
L	Blue	B/R	Black/Red
P	Pink	R/W	Red/White
Y	Yellow	R/Y	Red/Yellow
G	Green	W/R	White/Red
W	White	W/B	White/Black
Ch	Chocolate	W/G	White/Green
Dg	Dark green	Y/L	Yellow/Blue
Gy	Gray	Y/R	Yellow/Red
Sb	Sky blue	Y/G	Yellow/Green
Br	Brown	G/R	Green/Red
L/B	Blue/Black	G/Y	Green/Yellow
L/W	Blue/White	Br/W	Brown/White
L/Y	Blue/Yellow		




## ELECTRICAL COMPONENTS

- ① Main switch
- ② Flasher relay
- ③ Servomotor
- ④ Ignition coil
- ⑤ YPVS control unit
- ⑥ Neutral switch
- ⑦ Thermo switch
- ⑧ Horn
- ⑨ Cancelling unit
- ⑩ Except for Germany






- ① Sidestand switch
- ② Sidestand control unit
- ③ For Austria, Denmark, Sweden, England, Switzerland, Germany and Norway
- ④ Rectifier/Regulator
- ⑤ Reflector
- ⑥ Oil level switch
- ⑦ Battery
- ⑧ Rear brake switch
- ⑨ CDI unit



## IGNITION SYSTEM

CIRCUIT DIAGRAM (For AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY AND NORWAY)

Below circuit diagram shows ignition system.









- ① CDI magneto
- ③ Main switch
- ⑨ Sidestand control unit
- ⑩ "ENGINE STOP" switch
- ⑪ Sidestand switch
- ⑫ CDI unit
- ⑬ Ignition coil
- ⑭ Spark plug
- ⑮ Pickup coil
- ⑰ Neutral switch

NOTE: \_\_\_\_\_

For the color codes, see page 28.





## TROUBLESHOOTING

IF IGNITION SYSTEM SHOULD BECOME INOPERATIVE (NO SPARK OR INTERMITTENT SPARK).

Before this troubleshooting, remove following parts.

- Seat
- Lower cowl (For RD350LCF)
- Center cowls (For RD350LCF)
- Tail cowls (For RD350LCF)
- Fuel tank

## Ignition spark gap test

1. Warm up engine thoroughly so that all electrical components are at operating temperature.
2. Connect the Electro Tester (90890-03021) ① as shown.
- ② Spark plug lead
- ③ Spark plug
3. Start the engine, and increase the spark gap until misfire occurs (Test at various revolution between 1,200 ~ 10,000 r/min).

**CAUTION:**

Do not run the engine in neutral above 6,000 r/min for more than 1 or 2 seconds.

4. Check the minimum spark gap.



**Minimum Spark Gap:**  
6 mm (0.24 in)

## IGNITION SYSTEM


**ELEC**



Out of  
specification

OK

Ignition system is good.



### Main switch conduct check

1. Disconnect the main switch leads (Red, Brown, Black, Blue/White, Blue/Red, Black/White).
2. Connect the Pocket Tester (90890-03112) to main switch leads (Black, Black/White).

Tester (+) lead → Black/White lead  
Tester (–) lead → Black lead

### NOTE:

Set tester selector to "Ω × 1K" position.

3. Turn the main switch to "ON" position.


Discontinuity  
(∞)

Continuity  
(0Ω)

Main switch is faulty, replace it.

### "ENGINE STOP" switch conduct check

1. Disconnect the right handlebar switch leads (Red/Yellow, Blue, Black, Blue/Black, Green/Yellow, Brown).



2. Connect the Pocket Tester (90890-03112) to "ENGINE STOP" switch lead (Red/White, Black).

Tester (+) lead → Red/White lead  
 Tester (−) lead → Black lead


**NOTE:**

Set tester selector to " $\Omega \times 1K$ " position.

3. Turn the "ENGINE STOP" switch to "RUN" position.

Discontinuity ( $\infty$ )      Continuity ( $0\Omega$ )

"ENGINE STOP" switch is faulty,  
 replace right handlebar switch.

**Spark plug inspection**

1. Remove the spark plug.
2. Clean the spark plug with spark plug cleaner, if necessary.
3. Inspect electrode, insulator and plug gap. Refer to "CHAPTER 2—SPARK PLUG INSPECTION" section in the RD250LC/RD350LC SERVICE MANUAL (31L-28197-80).



Plug Gap:  
 0.7 ~ 0.8 mm (0.02 ~ 0.03 in)



OK

No good

Replace or regap spark plug.

### Ignition coil resistance test

1. Disconnect the ignition coil leads (Orange, Black) and the spark plug leads.

2. Connect the Pocket Tester (90890-03112) to ignition coil terminals.

**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1$ " position.

3. Measure the primary coil resistance.



**Primary Coil Resistance [A]:**  
0.28 ~ 0.38  $\Omega$  at 20°C (68°F)

4. Connect the Pocket Tester (90890-03112) to spark plug leads.


**NOTE:** \_\_\_\_\_

Set tester selector to " $\Omega \times 1K$ " position.


5. Measure the secondary coil resistance.



**Secondary Coil Resistance [B]:**  
4.72 ~ 7.08 K $\Omega$  at 20°C (68°F)







Both resistances  
meet specifications

Out of  
specification

Ignition coil is faulty, replace it.

### Pickup coil resistance test

1. Disconnect the pickup coil leads (White/Green, White/Red) at the CDI unit.
2. Connect the Pocket Tester (90890-03112) to the pickup coil leads.

Tester (+) lead → White/Green lead

Tester (–) lead → White/Red lead

### NOTE:

Set tester selector to " $\Omega \times 100$ " position.

3. Measure the pickup coil resistance.




Pickup Coil Resistance:

93.6 ~ 140.4  $\Omega$  at 20°C (68°F)

Resistance meets  
specification

Out of  
specification

Pickup coil is faulty, replace it.



### Source coil resistance test

1. Disconnect the source coil leads (Red, Green, Brown) at the CDI unit.
2. Connect the Pocket Tester (90890-03112) to the source coil leads.

Tester ( + ) lead → Brown lead  
Tester ( - ) lead → Red lead

NOTE: \_\_\_\_\_  
Set tester selector to " $\Omega \times 1$ " position.

3. Measure the source coil (1) resistance.



Source Coil (1) Resistance:  
3.6 ~ 5.4 $\Omega$  at 20°C (68°F)

4. Connect the Pocket Tester (90890-03112) to the source coil leads.



Tester ( + ) lead → Brown lead  
Tester ( - ) lead → Green lead


NOTE: \_\_\_\_\_  
Set tester selector to " $\Omega \times 100$ " position.

5. Measure the source coil (2) resistance.



Source Coil (2) Resistance:  
128.8 ~ 193.2 $\Omega$  at 20°C (68°F)



**Sidestand switch conduct check**

1. Disconnect the sidestand switch leads (Black, Blue/Yellow).
2. Connect the Pocket Tester (90890-03112) to the sidestand switch leads.

Tester (+) lead → Blue/Yellow lead  
 Tester (–) lead → Black lead

**NOTE:**

Set the tester selector to " $\Omega \times 1$ " position.

3. Place the motorcycle on its centerstand.
4. The sidestand is up and check the sidestand switch for continuity.

Continuity ( $0\Omega$ )      Discontinuity ( $\infty$ )

Sidestand switch is faulty, replace it.

**Neutral switch conduct check**


1. Disconnect the sidestand control unit leads (Black, Blue/White, Sky blue, Blue/Yellow).
2. Connect the Pocket Tester (90890-03112) to the neutral switch lead.

Tester (+) lead → Sky blue lead  
 Tester (–) lead → Frame earth

**NOTE:**

Set the tester selector to " $\Omega \times 1$ " position.

3. Transmission is in neutral and check the neutral switch for continuity.



## IGNITION SYSTEM

ELEC




Continuity  
(0Ω)

Discontinuity  
(∞)

Neutral switch is faulty, replace it.

### Sidestand control unit condition check

1. Disconnect the sidestand control unit lead ① (Brown).
2. Start the engine.



Poor condition  
(No spark or  
intermittent spark)

OK

Sidestand control unit is faulty,  
replace it.

Check entire ignition system for connections.  
(Refer to "WIRING DIAGRAM" section)

OK

Poor condition

Correct.

CDI unit is faulty, replace it.

## APPENDICES

### SPECIFICATIONS

#### GENERAL SPECIFICATIONS (FOR RD350LCF)

[DK]: For Denmark

[S]: For Sweden

[SF]: For Finland

[UK]: For England

Model	RD350LCF			
	1WT	1WU	1WW	1WX
Frame Starting Number	1WT-000101	1WU-000101	1WW-000101	1WX-000101
Engine Starting Number	1WT-000101	1WU-000101	1WW-000101	1WX-000101
Dimensions:				
Overall Length	2,095 mm (82.5 in) [DK, S] 2,120 mm (83.5 in) [SF] 2,126 mm (83.7 in)	2,120 mm (83.5 in)	←	←
Overall Width	700 mm (27.5 in)	←	←	←
Overall Height	1,190 mm (46.9 in)	←	←	←
Seat Height	790 mm (31.1 in)	←	←	←
Wheelbase	1,385 mm (54.5 in)	←	←	←
Minimum Ground Clearance	165 mm (6.5 in)	←	←	←
Weight:				
With Oil and Full Fuel Tank	159 kg (350 lb)	←	←	←
Engine:				
Displacement	347 cm <sup>3</sup>	352 cm <sup>3</sup>	347 cm <sup>3</sup>	←
Bore × Stroke	64.0 × 54.0 mm (2.520 × 2.126 in)	64.5 × 54.0 mm (2.540 × 2.126 in)	64.5 × 54.0 mm (2.520 × 2.126 in)	←
Spark plug:				
Type	BR9ES	←	←	BR8ES
Manufacturer	N.G.K.	←	←	←
Gap	0.7 ~ 0.8 mm (0.02 ~ 0.03 in)	←	←	←



Model	RD350LCF			
	1WT	1WU	1WW	1WX
Fuel:				
Type	Premium	Regular	Premium	Regular
Octane (Research)	Minimum 95	Non Lead	Minimum 95	Non Lead
Tank Capacity				
— Total	17 L (3.7 Imp gal, 4.5 US gal)	←	←	←
— Reserve	5 L (1.1 Imp gal, 1.3 US gal)	←	←	←
Transmission:				
Primary Reduction System	Helical gear	←	←	←
Primary Reduction Ratio	66/23 (2.869)	←	←	←
Secondary Reduction System	Chain	←	←	←
Secondary Reduction Ratio	39/17 (2.294)	39/18 (2.166)	39/17 (2.294)	←
Transmission Type	Constant mesh 6-spped	←	←	←
Bulb Wattage (Quantity):				
Headlight	60W/55W (1 pcs.)	←	←	←
Tail/Brake Light	5W/21W (2 pcs.)	←	←	←
Flasher Light	21W (4 pcs.)	←	←	←
Meter Light	3.4W (4 pcs.)	←	←	←
Auxiliary Light	4W (1 pcs.) [UK] 3.4W (1 pcs.)	←	←	←



[DK]: For Denmark  
[S]: For Sweden  
[N]: For Norway  
[UK]: For England

**GENERAL SPECIFICATIONS (FOR RD350LC)**

Model	RD350LC		
	1UA	1XA	1XE
Frame Starting Number	1WT-005101	1WW-002101	1WX-002101
Engine Starting Number	1WT-005101	1WW-002101	1WX-002101
Dimensions:			
Overall Length	2,095 mm (82.5 in) [DK, S, N] 2,120 mm (83.5 in)	2,120 mm (83.5 in)	←
Overall Width	700 mm (27.5 in)	←	←
Overall Height	1,070 mm (42.1 in)	←	←
Seat Height	790 mm (31.1 in)	←	←
Wheelbase	1,385 mm (54.5 in)	←	←
Minimum Ground Clearance	165 mm (6.5 in)	←	←
Weight:			
With Oil and Full Fuel Tank	155 kg (341.7 lb)	←	←
Spark plug:			
Type	BR9ES	←	BR8ES
Manufacturer	N.G.K.	←	←
Gap	0.7 ~ 0.8 mm (0.02 ~ 0.03 in)	←	←
Fuel:			
Type	Premium	←	Regular
Octane (Research)	Minimum 95	←	Non Lead
Tank Capacity			
—Total	17 L (3.7 Imp gal, 4.5 US gal)	←	←
—Reserve	5 L (1.1 Imp gal, 1.3 US gal)	←	←
Bulb Wattage (Quantity):*			
Headlight	60W/55W (1 pcs.)	←	←
Tail/Brake Light	5W/21W (2 pcs.)	←	←
Flasher Light	21W (4 pcs.)	←	←
Meter Light	3.4W (4 pcs.)	←	←
Auxiliary Light	4W (1 pcs.) [UK] 3.4W (1 pcs.)	←	←



## MAINTENANCE SPECIFICATIONS

Engine (For RD350LCF)

Model		RD350LCF			
		1WT	1WU	1WW	1WX
Cylinder:					
Material		Aluminum alloy	←	←	←
Sleeve Type		Cast-in Sleeve	←	←	←
Bore Size		64.00 ~ 64.02 mm (2.519 ~ 2.520 in)	64.50 ~ 64.52 mm (2.539 ~ 2.540 in)	64.00 ~ 64.02 mm (2.519 ~ 2.520 in)	←
< Limit >		64.1 mm (2.524 in)	64.6 mm (2.543 in)	64.1 mm (2.524 in)	←
Taper Limit		0.05 mm (0.002 in)	←	←	←
Out of Round Limit		0.01 mm (0.0004 in)	←	←	←
Piston:					
Piston Size		63.94 ~ 64.00 mm (2.517 ~ 2.519 in)	64.44 ~ 64.50 mm (2.537 ~ 2.539 in)	63.94 ~ 64.00 mm (2.517 ~ 2.519 in)	←
Measuring Point		10 mm (0.39 in)	←	←	←
Piston Clearance		0.060 ~ 0.065 mm (0.0024 ~ 0.0026 in)	←	←	←
< Limit >		0.1 mm (0.004 in)	←	←	←
Over Size	1st	64.25 mm (2.53 in)	64.75 mm (2.55 in)	64.25 mm (2.53 in)	←
	2nd	64.50 mm (2.54 in)	65.00 mm (2.56 in)	64.50 mm (2.54 in)	←
Carburetor:					
I.D. Mark		1UA 00	1WU 00	1XA 00	1XE 00
Main Jet	(M.J.)	# 185	# 210	# 185	# 180
Air Jet	(A.J.)	ø0.8	ø0.7	ø0.8	ø0.7
Jet Needle	(J.N.)	5L20-2	5CK2-3	5L20-2	5L20-3
Needle Jet	(N.J.)	N-8 ( # 544)	←	←	←
Cutaway	(C.A.)	2.0	←	←	←
Pilot Jet	(P.J.)	# 27.5	# 20	# 27.5	# 25
Air Screw	(Turns Out)	1 and 1/2	←	←	←
Valve Seat Size	(V.S.)	ø2.8	←	←	←
Starter Jet	(G.S.)	# 80	←	←	←
Power Jet	(Pw.J.)				
Right Hand Carburetor		# 60	# 55	# 60	# 20
Left Hand Carburetor		# 65	# 55	# 65	# 20
Engine Idle Speed		1,150 ~ 1,250 r/min	←	←	←











## Engine (For RD350LC)

Model	RD350LC		
	1UA	1XA	1XE
Carburetor:			
I.D. Mark	1UA 00	1XA 00	1XE 00
Main Jet (M.J.)	# 185	←	# 180
Air Jet (A.J.)	ø8	←	ø7
Jet Needle (J.N.)	5L20-2	←	5L20-3
Needle Jet (N.J.)	N-8 ( # 544)	←	←
Cutaway (C.A.)	2.0	←	←
Pilot Jet (P.J.)	# 27.5	←	# 25
Air Screw (Turns Out)	1 and 1/2	←	←
Valve Seat Size (V.S.)	ø2.8	←	←
Starter Jet (G.S.)	# 80	←	←
Power Jet (Pw.J.)			
Right Hand Carburetor	# 60	←	# 20
Left Hand Carburetor	# 65	←	# 20
Engine Idle Speed	1,150 ~ 1,250 r/min	←	←



## Tightening torque

Part Name	Thread Size	Nm	m•kg	ft•lb	Remarks
Cylinder head	M 8×1.25	28	2.8	20	
Cylinder	M 8×1.25	28	2.8	20	
Spark plug	M14×1.25	20	2.0	14	
Y.P.V.S. Valve	M 5×0.8	6	0.6	4.3	
Pulley	M 6×1.0	10	1.0	7.2	
Reed valve	M 6×1.0	10	1.0	7.2	
Joint cover (Thermostatic valve)	M 6×1.0	12	1.2	8	
Housing cover	M 6×1.0	8	0.8	5.8	
Radiator cover	M 5×0.8	3	0.3	2	
Joint (Cylinder head)	M 6×1.0	12	1.2	8	
Thermosenser		15	1.5	10	
Oil pump	M 5×0.8	5	0.5	3.6	
Reed valve assembly	M 6×1.0	15	1.5	11	
Primary drive gear	M16×1.0	65	6.5	47	
Clutch boss	M20×1.0	90	9.0	65	
Clutch spring	M 6×1.0	10	1.0	7.2	
Drive sprocket	M18×1.0	80	8.0	58	
Kick crank	M 8×1.25	25	2.5	18	
Shift pedal	M 6×1.0	10	1.0	7.2	
Flywheel magneto	M12×1.25	85	8.5	61	
Exhaust pipe	M 8×1.25	18	1.8	13	
Drain plug (Transmission)	M14×1.5	20	2.0	14	
(Coolant)	M 6×1.0	14	1.4	10	
Crankcase cover (R)	M 6×1.0	10	1.0	7.2	
(L)	M 6×1.0	7	0.7	5.1	
Crankcase (Lower)	M 8×1.25	8	0.8	5.8	
(Upper)	M 8×1.25	10	1.0	7.2	
Bearing cover plate	M 6×1.8	10	1.0	7.2	
Tachometer stopper plate	M 5×0.8	5	0.5	3.6	
Shift cam stopper plate	M 6×1.0	8	0.8	5.8	
Stopper lever	M 6×1.0	10	1.0	7.2	
Neutral switch	M 5×0.8	4	0.4	2.9	
Shift lever adjust screw	M 8×1.25	30	3.0	22	



## Chassis

Model	RD350LC/RD350LCF
Steering System:	
Steering Bearing Type	Ball bearing
No./Size of Balls	
Upper	19 pcs. 1/4 in
Lower	19 pcs. 1/4 in
Lock to Lock Angle	70°
Front Suspension:	
Front Fork Travel	140 mm (5.51 in)
Front Fork Spring	
Free Length < Limit >	416.6 mm (16.4 in) < 411.6 mm (16.2 in) >
Spring Rate	$K_1 = 3.9 \text{ N/mm}$ (0.4 kg/mm, 22.0 lb/in)
	0 ~ 140 mm (0 ~ 5.51 in)
Oil Capacity	282 cm <sup>3</sup> (9.9 Imp oz, 9.5 US oz)
Oil Level	128.7 mm (5.06 in)
Oil Grade	Fork oil 10wt or equivalent
Air Pressure (STD)	39 kPa (0.4 kg/cm <sup>2</sup> , 5.7 psi)
(Min. ~ Max.)	0 ~ 118 kPa (0 ~ 1.2 kg/cm <sup>2</sup> , 0 ~ 17 psi)
Drive Chain:	
Type/Manufacturer	520-V4/DAIDO
Number of Links	106
Chain Slack	30 ~ 40 mm (1.18 ~ 1.57 in)
Disc Brake:	
Type	
Front	Dual
Rear	Single
Disc Size-Outside Dia × Thickness	267 × 4.5 mm (10.5 × 0.18 in)
Disc Wear Limit	4.0 mm (0.16 in)
Pad Thickness	5.5 mm (0.22 in)
Pad Wear Limit	0.5 mm (0.02 in)
Master Cylinder Inside Diameter	
Front	15.87 mm (0.62 in)
Rear	12.70 mm (0.51 in)
Caliper Cylinder Inside Diameter	
Front	38.18 mm (1.5 in)
Rear	38.18 mm (1.5 in)
Brake Fluid Type	DOT #3



Electrical

Model	RD350LC/RD350LCF	
<b>CDI:</b> CDI Unit Model/Manufacturer Magneto Model/Manufacturer Pickup Coil Resistance (Color) Source Coil (1) Resistance (Color) Source Coil (2) Resistance (Color)	QAB49/NIPPON DENSO VCD88/NIPPON DENSO 93.6 ~ 140.4Ω at 20°C (68°F) (White/Red — White/Green) 3.6 ~ 4.5Ω at 20°C (68°F) (Brown — Red) 128.8 ~ 193.2Ω at 20°C (68°F) (Brown — Green)	
<b>Ignition Coil</b> Model/Manufacturer Minimum Spark Gap Primary Coil Resistance Secondary Coil Resistance	JO137/NIPPON DENSO 6 mm (0.24 in) 0.28 ~ 0.38Ω at 20°C (68°F) 4.72 ~ 7.08KΩ at 20°C (68°F)	
<b>A.C. Generator:</b> Model/Manufacturer Charging Out put Charging Coil Resistance (Color)	VCD88/NIPPON DENSO 14V, 13A at 5000 r/min 0.44 ~ 0.66Ω at 20°C (68°F) (White — White)	
<b>Voltage Regulator:</b> Type Model/Manufacturer No Load Regulated Voltage	Short Circuit SH569/SHINDENGEN 14.3 ~ 15.3V	
<b>Rectifier:</b> Model/Manufacturer Capacitd Withstand Voltage	SH569/SHINDENGEN 25A 200V	
<b>Horn:</b> Type Quantity Model/Manufacturer Maximum Amperage	Plane 1 pcs. YF3-12/NIKKO 2.5A	
<b>Flasher Relay:</b> Type Model Manufacturer Self Cancelling Device Flasher Frequency Wattage	[Except for Germany] Condenser FU249CD NIPPON DENSO Yes 75 ~ 95 cyl/min 21W × 2 + 3.4W	[For Germany] Semi transistor FJ245ED ← No ← ←



## SPECIFICATIONS


Model	RD350LC/RD350LCF
Oil Level Switch: Model/Manufacturer	34X/TAIHEIYO ASTI
Thermo-Unit: Model/Manufacturer	11H/NIHON SEIKI
*Sidestand Control Unit: Model/Manufacturer	4Y3/YAMAHA
*Sidestand Switch: Model/Manufacturer	33E/ASAHI DENSO

\*For AUSTRIA, DENMARK, SWEDEN, ENGLAND, SWITZERLAND, GERMANY and NORWAY.

**CABLE ROUTING (FOR RD350LCF)**

- ① Throttle cable
- ② Brake hose
- ③ Right handlebar switch lead
- ④ Left handlebar switch lead
- ⑤ Clutch cable
- ⑥ Meter lead
- ⑦ Headlight lead
- ⑧ Left flasher light lead
- ⑨ Right flasher light lead


- [A] Pass through the clutch cable behind the radiator.
- [B] Hold the wire harness with the clamp.






- ① To fuel tank
- ② Sidestand switch
- ③ Clamp
- ④ Sidestand switch lead
- ⑤ Headlight lead
- ⑥ Speedometer cable
- ⑦ Left flasher light lead
- ⑧ Horn
- ⑨ Clutch cable

- A Pass the fuel tank breather pipe through inside of the engine bracket.





- |                          |  |
|--------------------------|--|
| ① Wire harness           | ⑫ Fuse box   |
| ② Clamp                  | ⑬ Frame earth lead   |
| ③ Cancelling unit        | ⑭ Ignition coil  |
| ④ CDI unit               | ⑮ Battery breather pipe  |
| ⑤ Flasher relay          |  |
| ⑥ A.C. magneto lead      | A Pass the flasher light leads along inside of the frame.              |
| ⑦ Sidestand control unit | B Pass the battery breather pipe through inside of the engine bracket. |
| ⑧ Wire harness           |  |
| ⑨ Tail/Brake light lead  |  |
| ⑩ YPVS control unit      |  |
| ⑪ Oil level switch       |  |








# CABLE ROUTING (FOR RD350LCF)

- ① Clamp
- ② Brake hose
- ③ Clutch cable
- ④ YPVS cable
- ⑤ Autolube pump cable
- ⑥ AC magneto lead
- ⑦ Battery breather pipe
- ⑧ Rear brake switch

- ⑨ Rectifier/Regulator
- ⑩ Tail/Brake light lead
- ⑪ Band
- ⑫ Servomotor
- ⑬ Throttle cable
- ⑭ Battery negative lead
- ⑮ Battery positive lead

- [A] Pass the A.C. magneto lead through outside of the engine bracket.
- [B] Pass the rear brake switch lead through outside of the engine bracket.






## CABLE ROUTING (FOR RD350LC)

- ① Clutch cable
- ② Left handlebar switch lead
- ③ Throttle cable
- ④ Right handlebar switch lead
- ⑤ Main switch lead
- ⑥ Brake hose
- ⑦ Right flasher light lead
- ⑧ Wire harness
- ⑨ Left flasher light lead
- ⑩ Speedometer cable

- [A] Connect the meter leads inside of the headlight body.
- [B] Connect the flasher light leads inside of the headlight body.





① Wire harness

② Clamp

③ CDI unit

④ Flasher relay

⑤ A.C. magneto lead

⑥ Band

⑦ Sidestand control unit

⑧ Tail/Brake light lead

⑨ YPVS control unit

⑩ Oil level switch

⑪ Fuse box

⑫ Ignition coil

⑬ Cancelling unit


⑭ Horn

⑮ Horn lead

⑯ Battery breather pipe

**A** Pass the flasher light leads along inside of the frame

**B** Pass the battery breather pipe through inside of the engine bracket.



# CABLE ROUTING (FOR RD350LC)


APPX



- ① Brake hose
- ② Wire harness
- ③ YPVS cable
- ④ Clutch cable
- ⑤ Autolube pump cable
- ⑥ A.C. magneto lead
- ⑦ Battery breather pipe
- ⑧ Rear brake switch


- ⑨ Rectifier/Regulator
- ⑩ Tail/Brake light lead
- ⑪ Battery negative lead
- ⑫ Battery positive lead
- ⑬ Band
- ⑭ Servomotor
- ⑮ Throttle cable

- Ⓐ Pass the AC magneto lead through outside of the engine bracket.
- Ⓑ Pass the rear brake switch through outside of the engine bracket.




- ① To fuel tank
- ② Sidestand switch
- ③ Clamp
- ④ Sidestand switch lead

- A Pass the fuel tank breather pipe through inside of the engine bracket.



# **RD350LC/RD350LCF** **WIRING DIAGRAM** **FOR MODEL WITHOUT SIDESTAND SWITCH**



- ① "LIGHTS" switch
- ② "ENGINE STOP" switch
- ③ Front brake switch
- ④ Cancelling unit
- ⑤ YPVS-Motor
- ⑥ CDI unit
- ⑦ Ignition coil
- ⑧ Spark plug
- ⑨ Rear brake switch
- ⑩ Rectifier/Regulator
- ⑪ Battery
- ⑫ Rear flasher light (R)
- ⑬ Tail/brake light
- ⑭ Rear flasher light (L)
- ⑮ YPVS control unit
- ⑯ Oil level switch
- ⑰ Flasher relay
- ⑱ Fuse box
- ⑲ Neutral switch
- ⑳ CDI magneto
- ㉑ "HORN" switch
- ㉒ "TURN" switch
- ㉓ "PASS" switch
- ㉔ "LIGHTS" (Dimmer) switch
- ㉕ Front flasher light (L)
- ㉖ Main switch
- ㉗ Headlight
- ㉘ Auxiliary light
- ㉙ "TURN" indicator light
- ㉚ "HIGH BEAM" indicator light
- ㉛ "OIL" warning indicator
- ㉜ "NEUTRAL" indicator light
- ㉝ Tachometer
- ㉞ Temperature gauge
- ㉟ Reed switch
- ㊱ Meter light
- ㊲ Front flasher light (R)
- ㊳ Horn
- ㊴ Thermo switch

**COLOR CODE**

B	....Black
Br	....Brown
Ch	....Chocolate
Dg	....Dark green
G	....Green
Gy	....Gray
L	....Blue
O	....Orange
P	....Pink
R	....Red
Sb	....Sky blue
W	....White
Y	....Yellow
B/R	...Black/Red
B/W	...Black/White
B/Y	...Black/Yellow
Br/W	...Brown/White
G/R	...Green/Red
G/Y	...Green/Yellow
L/B	...Blue/Black
L/R	...Blue/Red
L/W	...Blue/White
R/W	...Red/White
R/Y	...Red/Yellow
W/B	...White/Black
W/G	...White/Green
W/R	...White/Red
Y/B	...Yellow/Black
Y/G	...Yellow/Green
Y/L	...Yellow/Blue
Y/R	...Yellow/Red